



ESS 7.0 | 9.0 | X

OPERATING MANUAL



Operating Manual ESS 7.0 | ESS 9.0 | ESS X

Document #30085-1

Version 1.6

Translation of original operating manual (German)

Copyrights

Version 06/2018

Copyright © BMZ GmbH

Subject to technical modifications that are required for advancements.

This operating manual or parts thereof may not be reproduced in any format (photocopy, micro film or other methods) or used, duplicated or processed with the help of electronic systems without a written consent of BMZ GmbH. In case of violations of these regulations, we reserve the right to claim damage compensation.

BMZ GmbH
Am Sportplatz 28
63768 Karlstein am Main
Germany

Phone:	+49 (0) 6188 9956 0
Service:	+49 (0) 6188 9956 9830
Fax:	+49 (0) 6188 9956 699
Webseite:	www.bmz-group.com
Service-Webseite:	www.bmz-central-service.com
Email:	CS.BigPack@bmz-group.com

About this manual

General

A qualified electrician must carry out installation, commissioning and maintenance. Please read this operating manual carefully to ensure a fault-free operation of the BMZ ESS battery storage system.

Please store this operating manual such that it is accessible to all persons who work on the BMZ ESS system.

Scope

This manual is intended for all products of the BMZ ESS series

- BMZ ESS 7.0
 - Art. No. 24930-xx
 - Art. No. 30110-xx
 - Art. No. 30890-xx
 - Art. No. 30891-xx
 - Art. No. 30892-xx
 - Art. No. 31555-xx
 - Art. No. 31560-xx
 - (Art. No. 32905-xx)
 - BMZ ESS 9.0
 - Art. No. 32370-xx
 - Art. No. 33741-xx
 - BMZ ESS X
 - Art. Nr. 37400-xx
 - Art. Nr. 37401-xx
-

Differentiation between an operating company and operator

The end consumer is referred to as an operating company in this manual. The system is installed and put into operation for this operating company.

A person, who works on the system or its controllers, is referred to as an operator in this manual. This person must be a qualified electrician authorised by BMZ GmbH.

Liability exclusion

BMZ GmbH does not bear any liability for damage resulting from unintended usage and non-adherence to this manual. This includes personal injuries, material damage, damage to the product as well as consequential damage, repair damage and other handling of the product by non-qualified electricians. This liability limitation is applicable even when non-original spare parts are used.

Carrying out arbitrary changes or technical modifications in the product is strictly prohibited.

A liability for profits lost or other costs and financial losses is ruled out.

Table of contents

About this manual	4
Table of contents.....	5
List of figures.....	8
1 Safety	10
1.1 Classification of warnings and intended use.....	11
1.1.1 Warnings in the operating manual.....	11
1.1.2 Intended use	12
1.2 Safety instructions to be followed	13
1.2.1 General safety instructions	13
1.2.2 Safety instruction when working with the tool.....	14
1.2.3 Safety instructions for transport and installation	15
1.2.4 Safety instructions for operation	16
1.2.5 Safety instructions for cleaning.....	18
1.2.6 Safety instructions for maintenance and dismantling	18
1.2.7 Safety instructions for battery interiors	21
1.2.8 Safety instructions for fire prevention	22
1.2.9 Explosion protection	23
1.2.10 Residual risks	24
1.3 Data and safety devices of the battery storage system.....	24
1.3.1 General hazard instructions and pictograms	24
1.3.2 Installed safety systems	26
1.3.3 Safety checks.....	26
2 Function, delivery scope and technical key variables	27
2.1 Function.....	27
2.2 Delivery scope.....	27
2.3 System overview	27
2.4 Rating plates and warning stickers.....	30
2.5 Technical key variables.....	31
3 Transport	32
3.1 Safety instructions for transport.....	32
3.2 Transporting the battery storage system.....	32
4 Installation, assembly and commissioning for the first time	36
4.1 Installation site requirements	36
4.2 Filling the installation check list.....	39
4.3 Installation of the battery storage system.....	40
4.4 Preparing the electrical connections for the single mode	41
4.4.1 Checking the connections	45
4.4.2 Switching the battery storage system on and off	45
4.4.3 Configuring the parameters of the inverter	46
4.5 Preparing the electrical connections for the parallel mode	47
4.6 Connection concept of multiple BMZ ESS batteries with one or more battery inverters.....	48
4.6.1 Communication	48

4.6.2	Contacting power cables	50
4.7	Configuration of the ESS parallel mode	55
4.7.1	1-phase operation of a SMA Sunny Island inverter on 1 ESS battery.....	55
4.7.2	1-phase operation of a SMA Sunny Island inverter on 2 ESS batteries	55
4.7.3	1-phase operation of a SMA Sunny Island inverter on 3 ESS batteries	56
4.7.4	3-phase operation of a SMA Sunny Island inverter on 3 ESS batteries	57
4.7.5	3-phase operation of a SMA Sunny Island inverter on 4 ESS batteries	58
4.7.6	3-phase operation of a SMA Sunny Island inverter on 5 ESS batteries	59
4.7.7	3-phase operation of a SMA Sunny Island inverter on 6 ESS batteries	60
4.7.8	3-phase operation of a SMA Sunny Island inverter on 9 ESS batteries	61
4.7.9	3-phase operation of a SMA Sunny Island inverter on 12 ESS batteries	62
4.8	Configuration of the ESS battery	63
4.8.1	System structure	63
4.8.2	Addressing the batteries	63
4.9	Definition of the battery mode during commissioning and parameter configuration ...	63
4.9.1	Single:	63
4.9.2	Master:	63
4.9.3	Slave:	63
4.10	Work step sequence to configure the parameters of batteries	64
4.11	Work step sequence to commission the batteries	65
4.12	Configuration of firmware for parallel mode	66
4.12.1	Setting the master battery mode	66
4.12.2	Setting the master battery address	67
4.12.3	Setting the slave battery mode	68
4.12.4	Setting the slave battery address	68
4.13	Commissioning the parallel connection of multiple batteries	69
4.13.1	Switch-on sequence	69
4.13.2	Stand-by mode of a slave battery:	69
4.13.3	Switch-on criterion of the slave battery:	69
4.13.4	Example 1:	70
4.13.5	Example 2:	70
4.13.6	Example 3:	71
4.14	Checking the parallel connection of multiple batteries	72
4.14.1	Check the number of connected (detected) batteries	72
4.14.2	Check the number of batteries for which the main relay is closed	73
4.15	Adding new batteries	73
4.16	Checking the connections of parallel battery systems	74
4.16.1	Switching the battery storage system on and off	74
4.16.1	Configuring the parameters of the inverter	76
4.17	Recommended parameters of the SMA Sunny Island inverter at the time of installation:	76
4.17.1	On-grid application	76
4.17.2	Off-grid application	78
5	Operation and service software	79
5.1	Pilot lamps (LED)	79
5.1.1	LED indicators on the battery module	79
5.1.2	Charging status indicator	80

5.2	Connection of the notebook for servicing	80
5.2.1	USB port	80
5.2.2	Service software	82
6	Fault/damage event.....	83
6.1	Fault indicators	83
6.1.1	Fault indicators of pilot lamps.....	83
6.2	Actions to be taken in case of a damage	84
6.2.1	First aid measures	84
7	Service and maintenance activities	85
7.1	Complaint handling	86
8	Warranty conditions	87
9	Dismantling and disposal.....	88
9.1	Disposal of the battery storage system.....	88
10	Annexe	89
10.1	Declaration of conformity	90
10.2	Installation check list.....	94

List of figures

Table 1-1 Hazard instructions, pictograms	25
Figure 1-2: battery storage system, side view of NH1 isolator	26
Table 2-1: delivery scope	27
Figure 2-2: battery storage system, front view	27
Figure 2-3: battery storage system, side view	28
Figure 2-4: battery storage system, side view	28
Figure 2-5: battery storage system, rear view	29
Figure 2-6: battery storage system, rear side	30
Figure 2-7: rating plate.....	30
Table 2-8: rating plate	30
Figure 2-10: recycling symbol	31
Figure 2-9: battery storage system, recycling symbol	31
Table 2-11: overview of technical specifications	31
Figure 3-1: seal position	33
Figure 3-2: seal position	33
Figure 3-3: transporting with the sack truck.....	35
Figure 4-1 : Requirements for the installation site, distance of the ESS from walls, top view	37
Figure 4-2 : Requirements for the installation site, distance of the ESS from walls, side view	37
Figure 4-3: representation of the pulled current isolator.....	40
Figure 4-4: inverter, connection area for battery lines.....	41
Figure 4-5: sample representation of the connection of plus and minus power cables with the SMA Sunny Island inverter	42
Figure 4-6: representation of external connections of the battery system, CAN	42
Figure 4-7: battery storage system, side view of the opened housing	43
Figure 4-8: representation of the correctly inserted fuses	43
Figure 4-9: battery storage system, side view	44
Figure 4-10: communication cabling, ESS parallel connection	48
Figure 4-11: RJ45 Y-adapter (even RJ45 T-connector).....	49
Figure 4-12: pin assignment of RJ45 Y-adapter (T-connector).....	49
Figure 4-13: battery storage system, side view, power isolator pulled	50
Figure 4-14: cable lengths of the ESS system.....	51
Figure 4-15: output cable of BAT Breaker Box.....	52
Figure 4-16: BAT BREAKER Box of Enwitec (example for 6 batteries and 3 inverters) with a closed housing.....	53
Figure 4-17: BAT BREAKER Box of Enwitec (example for 6 batteries and 3 inverters) with an open housing.....	54
Figure 4-18 : 1-phase operation on 1 ESS battery	55
Figure 4-19: 1-phase operation on 2 ESS batteries.....	55
Figure 4-20: 1-phase operation on 3 ESS batteries.....	56
Figure 4-21: 3-phase operation on 3 ESS batteries.....	57
Figure 4-22: 3-phase operation on 4 ESS batteries.....	58
Figure 4-23: 3-phase operation on 5 ESS batteries.....	59
Figure 4-24: 3-phase operation on 6 ESS batteries.....	60
Figure 4-25: 3-phase operation on 9 ESS batteries.....	61
Figure 4-26: 3-phase operation on 12 ESS batteries.....	62
Figure 4-27: representation of the BMZ ESS service tool	63
Figure 4-28: representation of the work sequence to configure the parameters of a BMZ ESS battery	64

Figure 4-29: representation of the work sequence to commission a BMZ ESS battery	65
Figure 4-30: file structure of the BMZ ESS service tool.....	66
Figure 4-31: representation of configuration of the parameters of a BMZ ESS battery	66
Figure 4-32: representation of configuration of the parameters of a BMZ ESS battery	67
Figure 4-33: representation of configuration of the parameters of a BMZ ESS battery	68
Figure 4-34: representation of configuration of the parameters of a BMZ ESS battery	68
Figure 4-35: block circuit diagram of the BMZ ESS slave battery.....	69
Figure 4-36: representation of example 1, different SOC of BMZ ESS batteries connected in parallel .	70
Figure 4-37: representation of example 2, different SOC of BMZ ESS batteries connected in parallel .	71
Figure 4-38: representation of example 3, different SOC of BMZ ESS batteries connected in parallel .	71
Figure 4-39: check the number of BMZ ESS batteries connected in parallel	72
Figure 4-40: check the number of BMZ ESS batteries connected in parallel	73
Figure 4-41: SMA on-grid parameters optimized for own consumption	77
Figure 4-42: SMA on-grid parameters optimized for backup power systems including own consumption	77
Figure 4-43: SMA off-grid parameters	78
Figure 5-1: Pilot lamps table (LED)	79
Figure 5-2: side view of BMZ ESS, service flap	80
Figure 5-3: push button with LEDs	80
Figure 5-4: USB communication	81
Figure 5-5: USB port of BMZ ESS battery, inner side of housing.....	81
Figure 5-6: push button and LEDs	81
Figure 10-1: EC Declaration of Conformity ESS 7.0 (1).....	90
Figure 10-2: EC Declaration of Conformity ESS 7.0 (2).....	91
Figure 10-3: EC Declaration of Conformity ESS 9.0	92
Figure 10-3: EC Declaration of Conformity ESS X.....	93
Figure 10-4: installation check list	94
Figure 10-5: installation check list, part 2	95

1 Safety

Target group

This section is aimed at all persons, including technical personnel, commissioning and shutdown personnel as well as personnel who work on the battery storage system.

Background

Safety has utmost priority.

Use all aids provided to you along with the measures and processes listed in this section to ensure a safe operation.

Get a detailed information about all safety aspects.

You should be aware of the fact that hazardous situations may always arise when handling battery storage systems.

Furthermore, the use of a battery storage is associated with the residual risks under the following circumstances:

- Installation and maintenance activities are not carried out properly.
 - Safety instructions given in this manual are not followed.
-

1.1 Classification of warnings and intended use

Safety instructions

This section describes warnings in this operating manual and the intended use of the machine.

1.1.1 Warnings in the operating manual

Warnings

Warnings serve as instructions and precautionary measures that must be followed and taken to avoid a hazardous situation.

Classification of warnings

Warnings can be classified depending on the magnitude of a hazardous situation. The classification is based on a probability assumption for an exposure to a hazardous situation and what could happen in such a case.

This manual differentiates between four warnings:

 DANGER	“DANGER” warns against hazardous situations. Prevent these hazardous situations. Otherwise, they will lead to deaths or serious injuries.
 WARNING	“Warning” warns against hazardous situations. Prevent these hazardous situations. Otherwise, they may lead to deaths or serious injuries.
 CAUTION	“CAUTION” , in combination with the warning icon, warns against hazardous situations. Prevent these hazardous situations. Otherwise, they may lead to insignificant or minor injuries.
ATTENTION	“ATTENTION” indicates a possible hazardous situation. Avoid these situations. Otherwise, they may damage the machine.

Note



This icon draws your attention to important, useful and helpful information.

1.1.2 Intended use

Intended use of the battery system

The BMZ ESS system must be exclusively used to store the current generated by the photovoltaic systems.

Foreseeable misuse

Any other use is considered to be unintended. BMZ GmbH shall not be responsible for damage resulted from this.

The BMZ ESS system is primarily **not** approved for the following usages:

- For a mobile use (e.g. on ships, in aeroplanes or in all types of land vehicles)
- For operation in outdoor areas
- For use in medical devices
- For use as a UPS system

 **DANGER**



Possible risk to life due to unintended usage

This battery system is exclusively intended for the aforementioned purpose. Any other use or a modification of the battery system without a written consent of the manufacturer is considered to be unintended.

The manufacturer will not assume liability for any resultant damage. The operating company shall bear full responsibility for any risk.

The battery system may be put into operation only if it is ensured that all safety devices have been installed and functioning properly.

Never install or operate a potentially or obviously defective battery storage.

Prevent these hazardous situations. Otherwise, they will lead to deaths or serious injuries.

Intended usage also implies compliance with the usage and operating instructions specified by the manufacturer as well as maintenance and servicing conditions.

1.2 Safety instructions to be followed

Safety instructions

Follow the safety instructions in this section to ensure the safety of persons and the system.

1.2.1 General safety instructions

Target group

These general safety instructions are intended for all operators and operating companies of the battery system. Each person, who is entrusted with the installation, commissioning, operation, cleaning, maintenance and repair activities, must have read and understood this operating manual, especially the **Safety** section.

Laws and regulations

Follow the instructions (regulations) of the relevant authorities as well as safety and operating instructions.

Spare parts

Only use original spare parts in case of repairs or when replacing the parts.



Using other parts that do not comply with our specifications may pose risks to persons and the system.



BMZ GmbH shall not be liable for personal injuries and/or material damage resulting from changes in the system.

Operator

Only a qualified electrician may operate/maintain the battery storage system.

 WARNING	
	Possible risk due to inadequately qualified persons Only a qualified electrician may carry out installation, servicing and maintenance activities.
	Prevent these hazardous situations. Otherwise, they may lead to deaths or serious injuries.

Suitable clothing (PPE)

Observe the following instructions regarding suitable clothing.

- Always wear protective shoes. Class S3
 - Always wear ESD protective clothing.
 - Wear suitable protective gloves.
 - Wear suitable protective goggles.
 - Do not carry electrically conductive objects (jewellery, rings, watches, chains)
-

Condition of the battery storage system

Keep the battery storage system clean and in an excellent condition. Operate the battery system only if it is in a flawless condition.

Other safety instructions

Follow the detailed safety instructions in Operation, Maintenance & Dismantling and Disposal sections.

1.2.2 Safety instruction when working with the tool

Target group

These safety instructions are intended for all persons who are entrusted with the transport and installation of the battery storage system.

Adhere to the operating manual

Always follow the instructions in the operating manual.

Working with the tool

Adhere to the following warning when using the tool:

 WARNING	
	A forgotten tool poses the risk of injuries. Do not keep any tools or metal parts on or in the battery. If a tool is not removed before commissioning, it may cause a short-circuit and injure persons or damage the system. • Only use the completely insulated tool. • Before commissioning/re-commissioning the battery system, ensure that there are no tools in the battery system. Prevent these hazardous situations. Otherwise, they may lead to deaths or serious injuries.

1.2.3 Safety instructions for transport and installation

Target group

These safety instructions are intended for all persons who are entrusted with the transport and installation of the battery storage system.

Adhere to the operating manual

Always follow the instructions in the operating manual.

Adhere to the installation manual

Always follow the instructions in the installation manual.

DANGER



Risk of life due to live components

There is a risk of life in case of a contact with live components.

- Only trained experts may work on the machine.
- When working on the current circuit or on the battery, always switch off the main switch first. Secure it with a padlock.
- When working on the current circuit or on the battery, always open the safety disconnection elements first. Secure the battery in which the disconnection elements are spatially separated and kept.
- Follow the 5 safety rules of battery technology.
- Never install or operate a potentially or obviously defective battery storage.

Prevent these hazardous situations. Otherwise, they will lead to deaths or serious injuries.

WARNING



Risk due to the loss of static stability

There is a risk of injuries due to the weight of the system.

- The system may tilt or fall in case of improper transport.
- Only use the transport aids that are suitable for the weight.
- Ensure the correct weight distribution of the system when transporting.
- The transport aids must provide a braking effect in case of a steep transport route.

Prevent these hazardous situations. Otherwise, they may lead to deaths or serious injuries.

Safety instructions for transport and installation, continued

! WARNING



Risk of injuries due to improper operation

Only trained experts may work on the system.

- In case of maintenance and repair activities, the danger area is extended by 1 m around the system. Pay attention to the swivel range of the opening flap.
- The operating company must ensure that the access to the danger area is prevented during the movement sequences.

Prevent these hazardous situations. Otherwise, they may lead to deaths or serious injuries.

1.2.4 Safety instructions for operation

Target group

These safety instructions are intended for all persons who are authorised to operate the battery storage system.

Adhere to the operating manual

Always follow the instructions in this operating manual when operating the battery storage system.

Safety instructions for operation

Only use original parts of the manufacturer or the components approved by the manufacturer for the energy storage unit.

! DANGER



Risk of life due to live components

When working on the electrical device, you may come in direct contact with parts carrying electric potential. Such a direct contact causes an electric shock.

- Follow the 5 safety rules of battery technology.
- Furthermore, only experts may maintain, modify or dismantle the battery storage system.
- Never install or operate a potentially or obviously defective battery storage.

Prevent these hazardous situations. Otherwise, they will lead to deaths or serious injuries.

Safety instructions for operation, continued

⚠ DANGER



Danger due to erupting fire (electric hazard)

Fire may erupt during operation due to sparks or heated surfaces.

- Follow the corresponding safety regulations (5 safety rules).
- Furthermore, only experts may maintain, modify or dismantle the battery storage system.
- Never install or operate a potentially or obviously defective battery storage.

Prevent these hazardous situations. Otherwise, they will lead to deaths or serious injuries.

⚠ WARNING



Health hazards due to negligent use of personal protective equipment

Working without personal protective equipment may cause serious injuries.

- Wear personal protective equipment (PPE).

Prevent these hazardous situations. Otherwise, they may lead to deaths or serious injuries.

⚠ WARNING



Danger due to burns (electric hazard)

When working on the electrical device, you may come in direct contact with defective and/or overloaded parts and get burns.

- Follow the 5 safety rules of battery technology.
- Furthermore, only experts may maintain, modify or dismantle the battery storage system.

Prevent these hazardous situations. Otherwise, they may lead to deaths or serious injuries.

1.2.5 Safety instructions for cleaning

Target group

These safety instructions are intended for all persons who are authorised to clean the battery storage system.

Adhere to the operating manual

Always follow the instructions in the operating manual when cleaning the battery storage system.

Safety instructions for cleaning

ATTENTION	
	Risk of damaged machine • Never clean the system or system parts using a vapour jet or spray water. Dirt and water may enter the system and cause major damage. • Use only a moist and clean cotton cloth for cleaning. Avoid these situations. Otherwise, they may damage the machine.

1.2.6 Safety instructions for maintenance and dismantling

Target group

These safety instructions are intended for all persons who are authorised to maintain/dismantle the battery storage system.

Adhere to the operating manual

Always follow the instructions in this operating manual when maintaining/dismantling the battery storage system.

Safety instructions for maintenance/dismantling

Observe the following warning when working on the electrical device:



 **DANGER**

Risk of life due to live components

There is a risk of life in case of a contact with live components.

- Only trained experts may work on the system.
- When working on the current circuit or on the battery, always switch off the main switch first. Secure it with a padlock.
- When working on the current circuit or on the battery, always open the safety disconnection elements first. Secure the battery in which the disconnection elements are spatially separated and kept.
- Pay attention to the risk of electric arcs when pulling the NH1 isolator under the full load of the battery
- Follow the 5 safety rules of battery technology.

Prevent these hazardous situations. Otherwise, they will lead to deaths or serious injuries.



 **DANGER**

Risk due to falling and being slung away

When working on the electrical device, a person may fall or slung away due to a contact with parts carrying electric potential or parts with electrostatic charges.

- Follow the corresponding safety regulations
- Furthermore, only experts may maintain, modify or dismantle the switch cabinet.

Prevent these hazardous situations. Otherwise, they will lead to deaths or serious injuries.

Safety instructions for maintenance/dismantling, continued

⚠ DANGER



Danger due to erupting fire (electric hazard)

Fire may erupt during operation due to sparks or heated surfaces.

- Follow the corresponding safety regulations (5 safety rules).
- Furthermore, only experts may maintain, modify or dismantle the switch cabinet.

Prevent these hazardous situations. Otherwise, they will lead to deaths or serious injuries.

⚠ WARNING



Health hazards due to negligent use of personal protective equipment

Working without personal protective equipment may cause serious injuries.

- Wear personal protective equipment (PPE).

Prevent these hazardous situations. Otherwise, they may lead to deaths or serious injuries.

⚠ CAUTION



Danger due to burns (electric hazard)

When working on the electrical device, you may come in direct contact with defective and/or overloaded parts and get burns.

- Follow the corresponding safety regulations
- Furthermore, only experts may maintain, modify or dismantle the switch cabinet.
- Pay attention to the risk of electric arcs when pulling the NH1 isolator under the full load of the battery

Prevent these hazardous situations. Otherwise, they may lead to insignificant or minor injuries.

1.2.7 Safety instructions for battery interiors

Target group

These safety instructions are intended for all persons who are authorised to work on battery modules of the battery storage system.

Adhere to the operating manual

Always follow the instructions in the operating manual and in the specifications when working on these modules.

Safety instructions for battery module



 **DANGER**

Danger due to leaking electrolyte

Only the trained experts and persons qualified and approved by BMZ GmbH may work on the battery. Modifications or manipulations in the battery may lead to considerable safety risks and are therefore prohibited.

- Do not solder cables to the battery.
- Do not short circuit the battery.
- Never open, dismantle, drill and crush the battery.
- Never allow the battery to fall.
- Do not expose batteries to rain or dip them in liquids.
- Do not touch damaged batteries with bare hands. Lithium can cause severe skin burns. Handle damaged batteries with suitable safety equipment and tools.
- Do not use defective, damaged or leaked batteries.
- Do not use batteries that show discolouration, deformations, unusual noises or severe heat.

Prevent these hazardous situations. Otherwise, they will lead to deaths or serious injuries.

Safety instructions for battery module, continued

 DANGER	
	Danger due to leaking electrolyte The materials / mediums to be used for intended operation of the battery storage system are procured and used by the manufacturer of the system. The manufacturer is thus solely responsible for the proper handling of these materials / mediums and the associated hazards. Hazard and disposal instructions must be provided by the manufacturer. Follow the safety data sheets of material and medium manufacturers. Prevent these hazardous situations. Otherwise, they will lead to deaths or serious injuries.

1.2.8 Safety instructions for fire prevention

Fire protection

Take essential precautions to respond efficiently in case of a fire.

Instructions for fire prevention

Pay attention to the following points:

- Keep the fire extinguisher(s) in the immediate vicinity of the system. (Fire extinguisher of fire class D)
 - Also keep in mind that poisonous vapours may be developed due to burning batteries and may hamper and damage the function of respiratory tracts.
-

Hazard due to fire

The battery storage system does not pose a fire hazard. In case of a fire in the system, avoid its spreading to other objects.

The battery storage system is de-energised at the time of delivery. Internal connection poles are always live. Therefore, ensure that a tool or a metallic object is not kept in the battery system. This could lead to a short-circuit and severe heat formation, which in turn could cause an explosion.

Actions to be taken in case of a damage



WARNING

Possible risk of life due to electric shock when quenching fire or due to flooding.

If you do not observe the following behavioural instructions, they may cause material damage and personal injuries; BMZ GmbH shall not bear any liability in such a case.

- Switch off the battery storage system if it is possible without any risk.
- Notify the fire brigade immediately.
- Help others and yourself to get out of the danger area immediately.
- Inform the fire brigade about the presence of Lithium-ion batteries.

Prevent these hazardous situations. Otherwise, they may lead to deaths or serious injuries.

Damaged cells and battery

Contact the manufacturer.

Never operate a potentially or obviously defective battery storage.

1.2.9 Explosion protection

General information

The battery storage system is de-energised at the time of delivery. Internal connection poles are always live. Therefore, ensure that a tool or a metallic object is not kept in the battery storage system. This could lead to a short-circuit and severe heat formation, which in turn could cause an explosion.

Explosive atmospheres

The battery storage system is not suitable for use in explosive atmospheres.

Ensure that there are no ignition sources in the within a radius of 3 m around the system.

1.2.10 Residual risks

General information

The battery storage system was designed such that no persons are exposed to avoidable hazards. Special danger areas are secured using special safety devices.

Despite this, some danger areas still remain. When working on the battery storage system, you must be aware of these danger areas, the actions to be taken to keep the risk of injuries and material damage minimal.

This operating manual contains safety instructions to indicate these danger areas and essential actions to minimise the risks resulting from such danger areas.

1.3 Data and safety devices of the battery storage system

Safety instructions

The data and devices for the safety of the battery storage system are specified in this section.

1.3.1 General hazard instructions and pictograms

Overview

Adhere to the safety systems and safety instructions described in this operating manual.

Keep the area around the battery storage system free from objects during operation to ensure that unhindered access is always possible.

- Pulling the NH isolator disconnects all outside battery poles.
- Pay attention to the risk of electric arcs when pulling the isolator under the full load of the battery.

Explanation of warning symbols and pictograms

The following warning symbols have been affixed on the battery storage system to be able to ensure the safety of personnel and the battery storage system:

Symbol	Explanation
	Warning against general hazard sources.
	Warning against electric potential.
	Warning against combustible materials.
	Warning against risks posed by batteries.
	Warning against electric shock.
	Do not dispose with household waste. Please return the battery storage system to the manufacturer.

Table 1-1 Hazard instructions, pictograms

1.3.2 Installed safety systems

Overview of safety systems of the battery storage system

Description	Position
NH isolator switch	Connection area: outer housing  Figure 1-2: battery storage system, side view of NH1 isolator

The externally accessible fuse elements (NH1) ensure the line protection and short-circuit protection.

1.3.3 Safety checks

General information

The following safety checks were conducted by the manufacturer in the factory.

Description	Position
Test scope	- Technical test of the battery management system for flawless scope of functions - Check whether communication between the battery and the inverter functions. - Cell voltage test - Temperature sensor test - Functional test of the battery at the inverter - Visual inspection of the finished product (outer housing) - Check the complete delivery scope.

2 Function, delivery scope and technical key variables

2.1 Function

Overview

The BMZ ESS energy storage system stores electric energy in its electro-chemical intermediate storage. This energy can then be retrieved later to compensate the daytime-dependent difference between the power generation and power consumption.

In combination with a suitable inverter, the BMZ ESS system also offers an option of standby power function in case of a mains failure.

Thanks to the modular system, the required storage capacity can be flexibly arranged on the basis of the BMZ ESS system.

2.2 Delivery scope

Overview of standard delivery scope

The BMZ ESS battery storage system is delivered with the following components:

Description	Quantity
BMZ ESS	1
Quick Guide ESS 7.0 9.0 X Installation with Sunny Island Products	1
Information sheet on off-grid operation	1

Table 2-1: delivery scope

2.3 System overview

Battery storage system: Front view



Figure 2-2: battery storage system, front view

Position	Description
1	Battery housing
2	Supporting feet (adjustable height)
3	Air suction

Battery storage system, side view




Figure 2-3: battery storage system, side view

Position	Description
1	Battery housing
2	Removable side wall with an inspection window and NH1 fuses
3	Supporting feet (adjustable height)
4	Air suction

Battery storage system, side view





Figure 2-4: battery storage system, side view

Position	Description
1	Battery housing
2	Air suction
3	Supporting feet (adjustable height)

Battery storage system, rear view



Position	Description
1	Battery housing
2	Air outlet with fan
3	Supporting feet (adjustable height)
4	RS485 bus for multi-parallel mode
5	USB port
6	PLUS line with 50 mm ²
7	CAN bus for inverter
8	MINUS line with 50 mm ²

Figure 2-5: battery storage system, rear view

2.4 Rating plates and warning stickers

General information

The rating plate is provided on the rear side of the battery.



Figure 2-6: battery storage system, rear side




Figure 2-7: rating plate

Position	Description
1	Manufacturer / address
2	QR code (contents: www.bmz-gmbh.de)
3	Safety instruction: Read the operating manual without fail before installation or usage
4	Safety instruction: Do not operate a defective battery
5	Safety instruction: The battery must not become wet.
6	Recycling instruction symbol
7	CE mark
8	Serial number
9	Manufacturing year/month
10	Product name
11	QR code (contents: serial number)
12	Safety instruction: various safety instructions

Table 2-8: rating plate

Recycling symbol



Figure 2-10: battery storage system, recycling symbol

Detailed view




Figure 2-9: recycling symbol

2.5 Technical key variables

Product data

The following table describes the variants of the BMZ ESS system:

Battery storage	Unit	BMZ ESS 7.0	BMZ ESS 9.0	BMZ ESS X
Energy content	kWh	6.743	8.5	10.06
Usable energy content	kWh	5.4	6.8	8.05
Nominal capacity C10	Ah	121.5	156.6	186.3
Nominal voltage	V	55.5	54.0	54.0
Expected calendar-based service life	a	15	15	15
Expected cycle stability		5000	5000	5000
Expected residual capacity at the end of service life	%	80	80	80
Degree of efficiency at 25 °C	%	>95	>95	>95
Cooling		active	active	active
Interfaces		CAN 2.0	CAN 2.0	CAN 2.0
Technology		Lithium Ion NMC	Lithium Ion NCA	Lithium Ion NCA
Self discharge rate per month	%	1-3	1-3	1-3
Dimensions H/W/D	cm	approx. 46 x 64 x 48	approx. 46 x 64 x 48	approx. 46 x 64 x 48
Weight	kg	95	97	99
Certifications		UN 38.3; CE	UN 38.3; CE	UN 38.3; CE

Table 2-11: overview of technical specifications

3 Transport

3.1 Safety instructions for transport

Target group

Safety instructions intended for the installation personnel who transport, install and put the BMZ ESS battery storage system in operation.

Safety instructions

For transporting the battery storage system and when working on electrical devices, please follow the safety instructions from the Safety section, page 10.

3.2 Transporting the battery storage system

Delivery of the battery storage system

Delivery The battery storage system is packed in a mechanically robust, three-walled corrugated paper carton and delivered.

Incoming inspection Check for the completeness using the delivery note.

Damage Check the delivery for damage.
Visual inspection: e.g. damaged packing, scratches, dents, paint damage, missing components
Is the delivery damaged during transport:

- **Ask the forwarding agent to acknowledge obvious transport damage in writing and on the site.**
 - **Contact the last forwarding agent immediately.**
 - **Store the packing (for a possible inspection by the forwarding agent or for returning the product).**
 - **Take photos for easier documentation.**
 - **Write a short fault report.**
 - **Never install or operate a potentially or obviously defective battery storage.**
-

Check the goods at the time of acceptance

Before accepting the goods, check whether the shipment is complete and flawless. The operating manual contains an exact list of all components.

Before accepting the goods, check whether the carton is broken, deformed or destroyed. In such case, refuse the acceptance or accept only with conditions and a written confirmation of the forwarding agent.

Immediately check whether the test seal in the battery is intact. The inner housing of the battery has 3 test seals. If one test seal is destroyed, refuse to accept the goods.

- ☛ If a test seal is destroyed, all guarantee and warranty claims for the product shall be void.
- ☛ If the test seal is destroyed: Do not install or commission the energy storage system under any circumstance.

Rear side of the battery inner housing



Figure 3-1: seal position

Front side of the battery inner housing



Figure 3-2: seal position

Contents of the seal:

Version 1: Warranty is VOID if this seal is broken (black seal)

Version 2: Warranty VOID if removed (silver seal)

Packing for return shipment

- If possible, use the original packing and the original packing material.
If both are no longer available, request a packing company with experts or contact the manufacturer.
- Place the transport units on a pallet (it must be designed depending on the weight).
- Use the original packing material to protect the housing from scratches and transport damage.

If you have queries regarding packing and transport safeguarding, please consult BMZ GmbH.

Contact

Telephone: +49 (0) 6188 9956 9830

Email: CS.BigPack@bmz-group.com

Intermediate storage

The freight packing of the battery, spare parts and replacement parts are designed for a storage duration of a maximum of 6 months from the delivery.

Storage conditions:

- Closed and dry room with a room temperature from +10 °C to +30 °C (temperatures below and above this range shorten the service life)
- Relative air humidity must be a maximum of 80% (non-condensing).
- The spatial distance from walls or other objects must be at least 50 cm.
- The battery storage system must be stored only in an upright position.

 Never clean the battery storage system or its immediate vicinity using a vapour jet or spray water. Dirt and water may enter the battery storage system and cause major damage.

 Before storing the lithium ion battery, inform your insurer.

After a storage time of a maximum of 6 months, execute an equalisation charge process for the battery as described in the operating manual of the battery inverter.

- If this is not done, batteries may get damaged.
- If this is not done, it will lead to consequential costs which will not be borne by BMZ.

The entire time of storage of batteries must be included in the usage duration.

Transport to the installation site (of the customer)

- Only the experts may carry out the transport in accordance with local conditions.
- The commercial installer is authorised to transport an energy storage unit without the ADR note for the transport of hazardous goods.
- The free limit for such “transports of hazardous goods” is 333 kg or 999 points (net weight of the hazardous product x 3 = points /ADR regulation). According to ADR, the identification of the vehicle is essential from 1000 points onwards and the driver must have an ADR note.
- Every transport must be provided with an accompanying document (transport document as per ADR hazardous goods UN3480) irrespective of the points.

The transport units are transported on pallets and exclusively in original packages up to the customer's installation site. The product must be installed out of the reach of children and animals.

! WARNING



Risk of injuries due to improper transport.

Pay attention to the weight of the transport unit when transporting (see technical specifications).

- The transport unit may tilt during transport. Pay attention to the centre of gravity.
- If necessary, secure the transport unit using suitable lifting tackles before transporting.

Prevent these hazardous situations. Otherwise, they may lead to deaths or serious injuries.

Transport with a sack truck



The sack truck must be designed for the weight of transport units.

Step	Description
1	Place the energy storage unit, with the contact with the rear wall, on the sack truck.  <i>Figure 3-3: transporting with the sack truck</i>  Use a soft protective cloth to protect the energy storage unit from scratches.  In case of steps, only use the specially designed step sack trucks.
2	Secure the energy storage unit with tightening straps on sack trucks.

4 Installation, assembly and commissioning for the first time

General information

Only the experts trained by BMZ GmbH may carry out the installation, assembly and first commissioning activities.

4.1 Installation site requirements

Installation site

The BMZ ESS battery storage system is only intended for usage in buildings. Usage of the battery only in non-living space. The battery housing has been designed for a stack of up to 3 battery storage systems. Use the structural analysis of the building to check whether it is designed for the load of the system. Each energy storage unit weighs approximately 99 kg. If three energy storage units are stacked on each other, intermittent loads of a maximum of 297 kg act on the floor.

The installation site must fulfil the following requirements:

- Levelled (e. g.: maximum setting range of adjusting feet)
- Dry (maximum air humidity 80%, non-condensing)
- Clean (well-swept, dust free)
- Vibration-free (maximum shock 0.5 g)
- No direct solar radiation
- No naked flames or other ignition sources near the installation place (minimum distance 3 m)
- Adequate distance (at least 20 cm) between the battery storage system and walls
- Adequate air circulation to dissipate the heat generated by the battery storage system.
- A maximum of three batteries can be stacked to tower.
- Installation site below 2000-metre altitude.

TOPVIEW




Figure 4-1 : Requirements for the installation site, distance of the ESS from walls, top view

SIDE VIEW




Figure 4-2 : Requirements for the installation site, distance of the ESS from walls, side view

The room air must not contain contaminations like suspended particles, metal dust or combustible gases. Ensure that the air humidity does not exceed 80%.

The room temperature should be in a range from 0 °C to 25 °C, wherein 15-20 °C are optimum for a long service life.



Operate the battery storage system only in the upright position.

- ☛ Ensure that the service flap at the side (NH1 fuses) is always freely accessible.

Install the battery inverter and the battery storage system near each other. Do not lay the connecting cable between the battery and the inverter in windings. The maximum length of this cable is 2.3 m.

Only use the provided original cable.

-  **Do not shorten the cable arbitrarily.**
-  **Do not extend the cable arbitrarily.**
-  **Do not lay the cable in loops.**

Immediate surroundings of the battery storage system

The immediate surroundings of batteries must be clean and dry. Oil contaminations, dirt or water residues must not be found outside the battery. If contaminations are found, remove them immediately. Additional information regarding this is given in: *VDE 0510 Part 2: 2001-12, EN 50272-2: 2001 "Safety requirements for batteries and battery systems – part 2: stationary batteries"*.


4.2 Filling the installation check list

The installer must fill the installation check list carefully; it shall be valid only with a signature and the company stamp. Store the completed installation check list carefully. In the annexe you will find a form of the installation check list. Warranty and guarantee claims against the manufacturer can only be made if the completed installation check list is submitted together with the warranty card and the original proof of purchase.

4.3 Installation of the battery storage system

Installation steps

Proceed as follows to install the battery storage system:

Step	Description
1	Unpack the battery storage system carefully and check it for transport damage. In case of transport damage, contact the forwarding agent or the manufacturer immediately.  Do not use a knife to open the packing.  Never install and operate a defective energy storage unit
2	Check whether all structural parts and accessories exist.
3	Check whether the battery storage system has been switched off.  Both LEDs must not light up.  Use a voltmeter to measure the DC voltage.
4	Bring the battery storage system on the pallet to the installation place using suitable transport aids.
5	Check whether the current isolator (NH isolator) is pulled.  <i>Figure 4-3: representation of the pulled current isolator</i>  The current isolator must be pulled before installation.
6	Use a suitable lifting device to lift the battery storage system from the pallet (e.g. workshop crane).
7	Position the battery storage system on the installation site.  Adhere to the minimum distances from walls. (See section 4.1 Requirements for the installation site)

4.4 Preparing the electrical connections for the single mode

Definition of single mode:

Single mode means the operation of a BMZ ESS energy storage system at an inverter.

Safety instructions

Please follow the safety instructions in the Safety section, page 10.

Establish the connections between the inverter and the battery

Pre-conditions:

- The current isolator (NH isolator) must be pulled
- The battery inverter must be switched off ("Off")

Check for the correct polarity carefully before establishing connections. Connection lines are marked in different colours:

- **Plus pole = RED**
- **Minus pole = BLACK**

The connection of a battery with an SMA Sunny Island inverter is described below as an example.



When using another inverter, please follow the specifications in the corresponding manufacturer's documentation.



Check whether the inverter used by you is approved for use with the BMZ ESS battery storage system.

Step	Description
1	Push the 50 mm² lines through metric screw joints into the housing of the inverter. Plus pole = RED Minus pole = BLACK  <i>Figure 4-4: inverter, connection area for battery lines</i>  The 50 mm² connection lines must NOT be connected to incorrect poles.  Follow the installation manual of the inverter manufacturer.

2

Connect the power cable of the battery inverter to the poles of the NT isolator.
Use the 2 screws of the M8x20 size as well as washers and tension washers.



Figure 4-5: sample representation of the connection of plus and minus power cables with the SMA Sunny Island inverter



Ensure that the contact surface of cable shoes rests completely.



Maximum tightening torque: 12 Nm. (Tolerance +/- 5 Nm)

3

Connect the CAN communication cable between the inverter and the battery storage system.
For this purpose, patch the patch cable (RJ45) from the **CAN socket** of the battery storage system to the **CAN socket** of the inverter. (Marked in yellow)




Figure 4-6: representation of external connections of the battery system, CAN

4

Insert the NH fuses in the cover of the NH isolator.



Figure 4-7: battery storage system, side view of the opened housing



Change the fuse inserts depending on the inverter to which the battery is connected.

Recommendation:

SI3.0M-11:	80 A
SI4.4M-11:	100 A
SI6.0H-11:	160 A
SI8.0H-11:	200 A




Figure 4-8: representation of the correctly inserted fuses

- 5 Insert the housing cover in the housing and tighten the screws of the cover.
For this purpose, use one DIN 7985 M4x6 fillister-head screws. Fix these using a PH2 Phillips screwdriver and a maximum tightening torque of 2.5 Nm (tolerance: +/-0.1 Nm).



Figure 4-9: battery storage system, side view



The cover may remain open during the first installation in order to switch on the battery. Close the cover after switching on the battery

- 6 Execute the first commissioning process by following the specifications from the Operation section (page 79).
- 7 Configure the parameters of the inverter as mentioned in section 4.18 (Recommended parameters).



Ensure that the batteries are not earthed by mistake. If they are earthed, disconnect the corresponding connection.



Check all parts for firm fitting. Re-tighten all screws and terminals.

4.4.1 Checking the connections

Check the connections as per the exact specifications in the installation check list given in the annexe.

4.4.2 Switching the battery storage system on and off

The battery storage system and the inverter must be correctly installed before they can be put into operation.

Switch on the battery storage system using a switch

Proceed as follows to start the battery storage system:

Step	Description
1	Open the screws on the service flat using a PH2 screwdriver.
2	Check whether the NH isolator is equipped with correct (see section 4.5) NH fuses and put into operation correctly.
3	Check the connections of the DC power cable (+, -) and the CAN communication cable of the battery inverter.
4	Actuate the push button through a short (longer than 1 second) push.   A clicking sound must be heard.
5	Check the LED status of the battery storage system. - The green LED flashes quickly (every 100 msec): The pre-charging path is activated and charges the capacitors of the inverter. (The pre-charging time depends on the type and number of connected inverters. The pre-charging time can take from 30 seconds to 2 minutes) - Both LEDs flashes slowly (every 1 second): The battery is active and waits for communication through the inverter.  The battery switches off automatically after 20 minutes if there is no communication between the battery and the inverter.  Additional information regarding the LED flashing patterns is given in the Pilot lamps section, page 80.
6	Switch on the battery inverter. The green LED lights up continuously  If there is no communication between the battery storage system and the inverter, the battery switches off automatically after 20 minutes to avoid erroneous operating modes. Both LEDs flash in a one-second cycle if there is no communication.

Switch on the battery storage system using an external voltage source

Proceed as follows to start the battery storage system:

Step	Description
1	The external voltage source can be used to switch on the system only if it was not switched off using the push button (press the push button longer than 10 seconds at a stretch).
2	Connect an external voltage source greater than 36 VDC.
3	The battery detects the external voltage source automatically and switches the operating mode from inactive to active.
4	If it is switched on in an unauthorised manner, the green LED flashes quickly (100 ms flash cycle) You must now start the battery using a normal switch-on sequence (by pressing the push button longer than 1 second).

Switch off the battery storage system using a push button

Proceed as follows to switch off the battery storage system:

Step	Description
1	Open the screws on the service flat using a PH2 screwdriver.
2	Keep the switch-on button pressed for at least 10 seconds. 
3	After approximately 8 seconds, both LEDs start flashing quickly (100 ms flash cycle).  Keep the button pressed for 2 more seconds.
4	The LEDs switch off. The battery storage system is now switched off.  A clicking sound must be heard.

Switch off the battery storage system using time

The battery switches off automatically after a defined time of 20 minutes when the battery does not detect any CAN communication externally.

Step	Description
1	If an external source (e.g. the battery inverter) does not detect a CAN communication of the battery, the battery switches off automatically after 20 minutes.

4.4.3 Configuring the parameters of the inverter

The inverter parameters must be configured for the BMZ ESS battery in order to operate it optimally in combination with the inverter.

See section 4.18

4.5 Preparing the electrical connections for the parallel mode

Definition of parallel mode:

Parallel mode means the operation of **multiple** BMZ ESS energy storage systems at **one or more** inverters.

Safety instructions

Please follow the safety instructions in the Safety section, page 10.

The following safety instructions are additionally applicable for the parallel operation:

- If the battery is operated under full load, housing parts and lines may generate heat.
 - When wiring the batteries, ensure that a short-circuit is never formed between the plus and minus poles of one or more batteries. There is a risk of life.
 - When laying the lines, do not extend them from the plus and minus poles.
 - When laying the lines (plus and minus poles), ensure that they are not rolled.
-

Establish the connections between the inverter and the battery

Pre-conditions:

- The current isolator (NH isolator) of each battery must be pulled
- The battery inverter must be switched off ("Off")
- Use a suitable switch cabinet to connect the batteries in the parallel circuit to the inverters.
BMZ recommends using a DC busbar with a suitable line fuse for each connected line.
BMZ recommends using products of SMA (Bat fuse) or Enwitec (BAT BREAKER BOX)

Check for the correct polarity carefully before establishing connections. Connection lines are marked in different colours:

- **Plus pole = RED**
- **Minus pole = BLACK**

Prerequisites for the battery firmware version



Batteries can be connected in parallel from firmware version V2.00 onwards.



The BMZ Service Tool in a specific version (at least Version 0.0.26) must be used to update the battery to a new firmware version.

Requirements for the battery inverter



The parallel connection capability of BMZ ESS batteries is approved only with the battery inverters of SMA Sunny Island.



Check whether the inverter used by you is approved for use with the BMZ ESS battery storage system.

4.6 Connection concept of multiple BMZ ESS batteries with one or more battery inverters

4.6.1 Communication

Wiring of the communication line from the battery to the inverter

- Connect the CAN cable to the battery that has been configured as the master and connected with the inverter.

Wiring of the communication line from between the batteries (internal communication of battery)

- All batteries in the parallel circuit are connected with each other via the RS485 bus for internal communication between them. The batteries are connected in a bus topology. For this purpose, T-connectors (or even Y-adapters) are used at the RJ45 sockets ("INTERNAL" label) of batteries.
- One T-connector (or even a Y-adapter) is used for each battery.




Figure 4-10: communication cabling, ESS parallel connection

- The RS485 bus must be closed with 120 Ohm at both ends

Example of a RJ45 T-connector (or even a Y-adapter) with corresponding pin assignment



Figure 4-11: RJ45 Y-adapter (even RJ45 T-connector)




Figure 4-12: pin assignment of RJ45 Y-adapter (T-connector)

4.6.2 Contacting power cables

Safety

ATTENTION	
	Risk of battery damage When switching on the battery, a wrong connection can cause a short circuit which destroys the battery fuse. When wiring the Bat Breaker Box (output rail): • Connect Pack PLUS only to Pack PLUS potentials. • Connect Pack MINUS only to Pack MINUS potentials.

Important:

When interconnecting the output contacts, all fuses (NH1 isolators) of individual batteries and the switch cabinet are **removed**, and the **automats** in the BAT BREAKER Box are set to **OFF**.



Figure 4-13: battery storage system, side view, power isolator pulled

Important:

Please refer to the installation manual „Batterie-Absicherung ‚BAT BREAKER‘ Typ ...“ by the company enwitec electronic for additional instructions regarding installation and operation.

Laying the power cables

- The power cable should be as short as required possible.
- The length of the Pack+ and Pack- cables must not exceed the respective maximum lengths.
- Cables of each battery (plus and minus poles) must always have the equal length.
- Cables of a battery connected in a parallel circuit must have the equal length between the batteries.




Figure 4-14: cable lengths of the ESS system

Connecting the power cables

- All plus poles of batteries must be laid on a copper rail using the Bat Breaker Box.
- All minus poles of batteries must be laid on a copper rail using the Bat Breaker Box.




Figure 4-15: output cable of BAT Breaker Box



Figure 4-16: BAT BREAKER Box of Enwitec (example for 6 batteries and 3 inverters) with a closed housing




Figure 4-17: BAT BREAKER Box of Enwitec (example for 6 batteries and 3 inverters) with an open housing

4.7 Configuration of the ESS parallel mode

Thanks to the modular concept of the BMZ ESS system, different configurations of BMZ ESS batteries with SMA Sunny Island inverters are possible.

4.7.1 1-phase operation of a SMA Sunny Island inverter on 1 ESS battery




Figure 4-18 : 1-phase operation on 1 ESS battery

4.7.2 1-phase operation of a SMA Sunny Island inverter on 2 ESS batteries




Figure 4-19: 1-phase operation on 2 ESS batteries

4.7.3 1-phase operation of a SMA Sunny Island inverter on 3 ESS batteries




Figure 4-20: 1-phase operation on 3 ESS batteries

4.7.4 3-phase operation of a SMA Sunny Island inverter on 3 ESS batteries




Figure 4-21: 3-phase operation on 3 ESS batteries

4.7.5 3-phase operation of a SMA Sunny Island inverter on 4 ESS batteries




Figure 4-22: 3-phase operation on 4 ESS batteries

4.7.6 3-phase operation of a SMA Sunny Island inverter on 5 ESS batteries




Figure 4-23: 3-phase operation on 5 ESS batteries

4.7.7 3-phase operation of a SMA Sunny Island inverter on 6 ESS batteries




Figure 4-24: 3-phase operation on 6 ESS batteries

4.7.8 3-phase operation of a SMA Sunny Island inverter on 9 ESS batteries




Figure 4-25: 3-phase operation on 9 ESS batteries

4.7.9 3-phase operation of a SMA Sunny Island inverter on 12 ESS batteries




Figure 4-26: 3-phase operation on 12 ESS batteries

4.8 Configuration of the ESS battery

4.8.1 System structure

- In a complete system of batteries connected in parallel, configure **one battery** as a “**master**”.
- In a complete system of batteries connected in parallel, configure **all other batteries** as “**slave**”.
- You can connect up to 6 batteries with each other in parallel.

4.8.2 Addressing the batteries

- Configure each battery with an unambiguous and unique address.
Numbers 1 to 12 are available.

Note: Each battery must have a different bus address (device address).

Note: Do not use Device address “0”.

4.9 Definition of the battery mode during commissioning and parameter configuration




Figure 4-27: representation of the BMZ ESS service tool

4.9.1 Single:

This is the delivery status of every BMZ ESS battery ex-works.

The mode is used for the status: 1 BMZ ESS battery operated at one SMA Sunny Island inverter.

4.9.2 Master:

This is the status of a BMZ ESS battery in a group of multiple BMZ ESS batteries connected in parallel.

Important: Only one battery may be configured as a master.

The mode is used for the status: multiple BMZ ESS batteries are operated at one or more SMA Sunny Island inverters.

4.9.3 Slave:

This is the status of multiple BMZ ESS batteries in a group of multiple BMZ ESS batteries connected in parallel.

Important: Each battery, except the master battery, must be configured as a slave battery.

The mode is used for the status: multiple BMZ ESS batteries are operated at one or more SMA Sunny Island inverters.

4.10 Work step sequence to configure the parameters of batteries

Execute the following steps to configure the parameters of batteries for a system comprising ESS batteries connected in parallel.




Figure 4-28: representation of the work sequence to configure the parameters of a BMZ ESS battery

4.11 Work step sequence to commission the batteries

Execute the following steps to commission a system comprising ESS batteries connected in parallel.




Figure 4-29: representation of the work sequence to commission a BMZ ESS battery

4.12 Configuration of firmware for parallel mode

Use the BMZ service tool to configure the battery using the USB service port.

The following files must be available to configure the battery parameters:

1. ESS30ServiceTool.exe (example: current service tool V0.0.26)
2. System.Windows.Interactivity.dll
3. Optional for firmware update: 31502A_V206.flash (example: current firmware V2.06)

Important: All three files must be in the same folder.

Name	Änderungsdatum	Typ	Größe
 31502A_V203.flash	22.03.2016 14:13	FLASH-Datei	113 KB
 ESS30ServiceTool.exe	01.04.2016 15:04	Anwendung	3.157 KB
 System.Windows.Interactivity.dll	26.02.2016 15:50	Anwendungserwe...	55 KB

Figure 4-30: file structure of the BMZ ESS service tool

4.12.1 Setting the master battery mode

In a group of multiple BMZ ESS batteries connected in parallel, configure **one battery** as a **master**.

Important:

1. Set the “**Master**” mode and configure the battery parameters by **clicking** on “**set mode**”.
2. In a group of multiple BMZ ESS batteries connected in parallel, **only one battery** may be configured as a master.




Figure 4-31: representation of configuration of the parameters of a BMZ ESS battery

3. **IMPORTANT:** Configure the parameters of the battery with the lowest voltage level and the lowest charge status as the master battery.

4.12.2 Setting the master battery address

- Address 0 is the default address. Do not use Address 0. Type in + or – to get to device address 1 or higher.
- Each battery connected in parallel must have an unambiguous and unique address (device address).
- The master and slave batteries function only with the addresses configured with numbers from 1 to 12.




Figure 4-32: representation of configuration of the parameters of a BMZ ESS battery

Important:

1. Set the “address” (device address) to “1” and configure the battery parameters by clicking on “set address”.
2. In a group of multiple BMZ ESS batteries connected in parallel, **only one battery** may have the address “1”.
3. If you use device address “1” please make sure that you typed in “+” and “-” before so that “1” will be recognized from the battery BMS.

4.12.3 Setting the slave battery mode

In a group of multiple BMZ ESS batteries connected in parallel, configure all batteries, except the master, as slaves.

Important:

1. Set the “Slave” mode and configure the battery parameters by clicking on “set mode”.




Figure 4-33: representation of configuration of the parameters of a BMZ ESS battery

4.12.4 Setting the slave battery address

- Address 0 is the default address.
- Each battery connected in parallel must have an unambiguous and unique address (device address).
- The master and slave batteries function only with the addresses configured with numbers from 1 to 12.




Figure 4-34: representation of configuration of the parameters of a BMZ ESS battery

Important:

1. Set the “address” (device address) to “2” and configure the battery parameters by clicking on “set address”.
2. In a group of multiple BMZ ESS batteries connected in parallel, **only one battery** may have the address “2”.
3. Configure a unique and unambiguous address (device address) for all other slave batteries.

4.13 Commissioning the parallel connection of multiple batteries

4.13.1 Switch-on sequence

1. At the time of **commissioning**, **first switch on the master battery**.
2. Check whether the **main relay** of the **master battery** is **switched on**
-> Check via LED flashing speed (see section 5.1) or BMZ service tool (see section 4.4)
3. **If the main relay of the master battery is closed, you can now switch on other slave batteries.**

4.13.2 Stand-by mode of a slave battery:

When you switch on the slave batteries, the batteries are automatically in the stand-by mode. (The stand-by mode is indicated by a green flashing LED) Only when the master sends a switching signal for the main relay of the slave battery, the main relay of the slave battery is switched on. The slave battery can be used the complete battery system only after this.

4.13.3 Switch-on criterion of the slave battery:

Each battery compares the internal battery voltage with the externally applied voltage through a measurement.




Figure 4-35: block circuit diagram of the BMZ ESS slave battery

If the voltage automatically measured by the battery at the master battery differs from the slave battery voltage by less than ± 100 mV, the slave battery switches off automatically.

Important:

To ensure that all slave batteries are activated from the master battery in case of a different voltage level for different batteries, change the charge status of the master battery by charging and discharging using the inverter.

Within a full cycle (i.e. the battery is completely charged once and completely discharged once), the master battery scans all slave batteries in the stand-by mode and switches them off one by one.

This process may take a few hours depending on the available PV energy or loads in the company network.

4.13.4 Example 1:

6 batteries connected in parallel with different charge statuses:

- The master battery is switched on and the main relay is switched on
- 2 slave batteries are switched on and the main relay is switched on
- 3 slave batteries are switched on and the main relay is **NOT** switched on




Figure 4-36: representation of example 1, different SOC of BMZ ESS batteries connected in parallel

4.13.5 Example 2:

6 batteries connected in parallel with different charge statuses:

- The master battery is switched on and the main relay is switched on
- 4 slave batteries are switched on and the main relay is switched on
- 1 slave battery is switched on and the main relay is **NOT** switched on




Figure 4-37: representation of example 2, different SOC of BMZ ESS batteries connected in parallel

4.13.6 Example 3:

6 batteries connected in parallel with different charge statuses:

- The master battery is switched on and the main relay is switched on
- 5 slave batteries are switched on and the main relay is switched on




Figure 4-38: representation of example 3, different SOC of BMZ ESS batteries connected in parallel

4.14 Checking the parallel connection of multiple batteries

4.14.1 Check the number of connected (detected) batteries

- Connect the notebook to the master battery.
- The “Detected devices” number shows the number of batteries connected to the master (and that are in the stand-by mode).




Figure 4-39: check the number of BMZ ESS batteries connected in parallel

Other test criterion: The LED of a battery in the stand-by mode flashes green.

4.14.2 Check the number of batteries for which the main relay is closed

- Connect the notebook to the master battery.
- The “Devices with closed switch” number shows the number of batteries connected to the master for which the main relay is closed.
- These batteries are connected in parallel to the master battery and can thus be used in the complete system (charging and discharging).




Figure 4-40: check the number of BMZ ESS batteries connected in parallel

Other test criterion: The LED of a battery in the parallel mode (active) continuously lights up in green.

4.15 Adding new batteries

BMZ allows subsequent extensions of the battery system until six months after the first installation.

- 1) Configure a new battery as a slave
- 2) Disconnect the NH isolator of the output rail
- 3) Disconnect the NH isolator of the battery
- 4) Connect the power cable of the slave battery to the output rail.
- 5) If the new slave battery is switched on, switch it off by pressing the button for 10 seconds (LEDs must be off)
- 6) Connect the NH isolator of the battery
- 7) Connect the NH isolator of the output rail
- 8) Switch on the slave battery using the button (press the button for > 1 second, LEDs flash)

After adding a new battery, you may still need to deal with the equalising currents. This may lead to the adjustment of the capacity even if no current flows from or to the inverter.

4.16 Checking the connections of parallel battery systems

Check the connections as per the exact specifications in the installation check list given in the annexe.

4.16.1 Switching the battery storage system on and off

The battery storage system and the inverter must be correctly installed before they can be put into operation.

Switch on the battery storage system using a switch

Proceed as follows to start the battery storage system:

Step	Description
1	Open the screws on the service flat using a PH2 screwdriver.
2	Check whether the NH isolator is equipped with correct (see section 4.5) NH fuses and put into operation correctly.
3	Check the connections of the DC power cable (+, -) and the CAN communication cable of the battery inverter.
4	Actuate the push button through a short (longer than 1 second) push.  A clicking sound must be heard.
5	Check the LED status of the battery storage system. - The green LED flashes quickly (every 150 msec): The pre-charging path is activated and charges the capacitors of the inverter. (The pre-charging time depends on the type and number of connected inverters. The pre-charging time can take from 30 seconds to 2 minutes) - For slave batteries: The green LED flashes slowly (every 1 second): The battery is active and waits for the switch-on signal of the master battery. - Both LEDs flashes slowly (every 1 second): The battery is active and waits for communication through the inverter.  The battery switches off automatically after 20 minutes if there is no communication between the battery and the inverter.  Additional information regarding the LED flashing patterns is given in the Pilot lamps section, page 80.
6	Switch on the battery inverter. The green LED lights up continuously  If there is no communication between the battery storage system and the inverter, the battery switches off automatically after 20 minutes to avoid erroneous operating modes. Both LEDs flash in a one-second cycle if there is no communication.

7	Important: (see chapter 4.14.1) At the time of commissioning of batteries connected in parallel, first switch on the master battery. 1. Check whether the main relay of the master battery is switched on -> Check via LED flashing speed (see section 5.1) or BMZ service tool (see section 5.2) - If the main relay of the master battery is closed, you can now switch on other slave batteries. If the switch-on sequence for batteries connected in parallel is not followed, it may happen that none of the batteries allow switching off the main relay.
---	--

Switch on the battery storage system using an external voltage source

Proceed as follows to start the battery storage system:

Step	Description
1	The external voltage source can be used to switch on the system only if it was not switched off using the push button (press the push button longer than 10 seconds at a stretch).
2	Connect an external voltage source greater than 36 VDC.
3	The battery detects the external voltage source automatically and switches the operating mode from inactive to active.
4	If it is switched on in an unauthorised manner, the green LED flashes quickly (100 ms flash cycle) You must now start the battery using a normal switch-on sequence (by pressing the push button longer than 1 second).

Switch off the battery storage system using a push button

Proceed as follows to switch off the battery storage system:

Step	Description
1	Open the screws on the service flat using a PH2 screwdriver.
2	Keep the switch-on button pressed for at least 10 seconds. 
3	After approximately 8 seconds, both LEDs start flashing quickly (100 ms flash cycle).  Keep the button pressed for 2 more seconds.
4	The LEDs switch off. The battery storage system is now switched off.  A clicking sound must be heard.

Switch off the battery storage system using time

The battery switches off automatically after a defined time of 20 minutes when the battery does not detect any CAN communication externally.

Step	Description
1	If an external source (e.g. the battery inverter) does not detect a CAN communication of the battery, the battery switches off automatically after 20 minutes.
2	Optional: If the battery is installed in parallel mode , the battery defined as master first switches off after 20 minutes without CAN communication of the external source. The slave battery then switches off after 20 minutes. If a master or a slave battery is now switched on in the parallel mode, all batteries in the complete system are switched on since they are activated by the pre-charging voltage of the battery that is switched on first (see Switching on the battery storage system using an external voltage source)

4.16.1 Configuring the parameters of the inverter

The inverter parameters must be configured for the BMZ ESS battery in order to operate it optimally in combination with the inverter.

See section 4.18



4.17 Recommended parameters of the SMA Sunny Island inverter at the time of installation:

In order to ensure the optimum working range of the battery and to optimise the quantity of storable energy, the battery manufacturer has given the following recommendations for the parameters of the inverter:

-  A detailed description of parameters is given in the operating manual of your SMA Sunny Island inverter.
-  Amongst the recommended parameters, we differentiate between "On-grid" and "Off-grid" applications.

4.17.1 On-grid application

- Enter the following values in the quick configuration guide during the basic configuration of the Sunny Island inverter (see the documentation of the system):
 - Battery type **BatTyp**: Lilon_Ext-BMS
 - Battery capacity **BatCpyNom**: For Ah values see type plate on the battery's backside (C10). Multiply the value for each battery in parallel.
- After the basic configuration of the Sunny remote control, turn the knob and select the input page **password (1/1)**.
- Press the knob. This will take you to the input page.
- Calculate the checksum of the **Runtime** operating hours. Determine the installer password.
 - Example: The **Runtime** operating hours are **1234 h**. The checksum is the sum of all digits:
 $1 + 2 + 3 + 4 = 10$
- Select **Set** on the Sunny remote control and press the knob.
- Set the determined installer password and press the knob.

The Sunny remote control is in the installer mode.

7. Select the **700# Operator Level** menu and press the knob.
8. Select the **700.01 ActLev** parameter, press the knob and set to **Expert**.
9. Confirm the **<accept Y/N>** query with **Y**.
10. Set the following parameters to the specified values only to optimize the Sunny Island units for own consumption or for backup power systems including own consumption.

```
Installer
100# Meters
200# Settings
300# Diagnosis
```

```
Installer
500# Operation
600# Direct Access
700# Operator Level
```

```
Operator Level
700#01 <Set>
ActLev
Expert
```

Number	Name	Value
261.03	Season enable	No
262.01	ProtResSOC	3%
262.02	BatResSOC	2%
262.04	PVResSOC	5%
262.05	MinSlfCsmplSOC	90%

Figure 4-41: SMA on-grid parameters optimized for own consumption

Number	Name	Value
261.03	Season enable	No
262.01	ProtResSOC	3%
262.02	BatResSOC	2%
262.03	BUResSOC	1%
262.04	PVResSOC	5%
262.05	MinSlfCsmplSOC	89%

Figure 4-42: SMA on-grid parameters optimized for backup power systems including own consumption

-  In order to optimise the efficiency of the battery, the battery automatically executes a learning cycle at periodic intervals, wherein the actually usable capacity of the battery is automatically determined.
-  In this learning cycle, the battery must cover the SOC limits of 100% and 12% as frequently as possible. The learning cycle starts at 100% SOC (battery full) and ends at 12% SOC. If both incidents occur in succession and, in the meantime, the energy is not charged more than 20% SOC, then the learning cycle is evaluated as “successfully executed”.
-  The higher the frequency of execution of this learning cycle, the more precise is the SOC calculation.
-  The higher the frequency of execution of this learning cycle, the more the energy that the battery can save and transfer.

4.17.2 Off-grid application

In the expert mode, set the following parameters when installing the inverter:

Number	Name	Value
	Diesel generator request	12% SOC
	Load dropping relay	10% SOC
	Bat Pro 3	3% SOC
	Bat Pro 2	5% SOC
	Bat Pro 1	7% SOC

Figure 4-43: SMA off-grid parameters

-  In order to optimise the efficiency of the battery, the battery automatically executes a learning cycle at periodic intervals, wherein the actually usable capacity of the battery is automatically determined.
-  In this learning cycle, the battery must cover the SOC limits of 100% and 12% as frequently as possible. The learning cycle starts at 100% SOC (battery full) and ends at 12% SOC. If both incidents occur in succession and, in the meantime, the energy is not charged more than 20% SOC, then the learning cycle is evaluated as “successfully executed”.
-  The higher the frequency of execution of this learning cycle, the more precise is the SOC calculation.
-  The higher the frequency of execution of this learning cycle, the more the energy that the battery can save and transfer.

5 Operation and service software

General safety instructions

Please follow the safety instructions in the Safety section, page 10.

5.1 Pilot lamps (LED)

5.1.1 LED indicators on the battery module

The pilot lamps on the battery module indicate the possible statuses and incidents in the operation of the battery storage system.

Colour pattern	Flashing frequency	Function
OFF	OFF	The battery is switched off
Green + Red	Continuously lit up	Service mode (a PC is connected)
	Quick flashing (100msec)	The battery is in error mode - The relay is tripped and cannot be switched on - For example, the temperature is too high - For example, the temperature is too low - For example, charge status of battery is too low Please contact the BMZ Service immediately (see section (7))
	Slowly flashing (1sec)	The battery is switched on, but no communication with the inverter. (Countdown of 20 minutes until the battery is switched off)
Green	Continuously lit up	The battery is switched on (normal mode) - The relay is pulled - The inverter is fed via Softstart (pre-charging branch) - No error
	Slowly flashing (1sec)	Pre-charging is activated. (Normal mode) The pre-charging path for charging the capacitors of the inverter is activated The relay is still not pulled
	Slowly flashing (1sec)	SLAVE battery (normal mode) - The pre-charging path for charging the capacitors of the inverter is activated - The relay is still not pulled (master not active) - The battery is in stand-by mode and switches off automatically as soon as the master is activated.
Red	Quick flashing (100ms)	The battery is in error mode - The relay is tripped and cannot be switched on - The 2nd protection switch element (Pyrofuse) has tripped Please contact the BMZ Service immediately (see section (7))

Figure 5-1: Pilot lamps table (LED)

5.1.2 Charging status indicator

The charging status indication is given using the communication line via the inverter.

5.2 Connection of the notebook for servicing

5.2.1 USB port

Each rechargeable battery set has a USB port.

The installer can use this port to execute the following steps:

- Update (firmware)
- Read error memory

Proceed as follows to read the battery storage system via the USB port:

Step	Description
1	Open the screws on the service flat using a PH2 screwdriver. Loosen and remove the upper fillister-head screw of the lateral service flap.  <i>Figure 5-2: side view of BMZ ESS, service flap</i>
2	Now push the flap of the side panel upwards to remove it.
3	Switch off the battery system.  <i>Figure 5-3: push button with LEDs</i>  Both LEDs must not light up.
4	Pull out the NH fuses of the NH isolator and remove the safety bracket and fuses from the isolator.

5

Connect the notebook to the battery storage system.
 Connect the USB A cable of the notebook to the USB A port of the battery storage system.



Figure 5-4: USB communication

5a

This step is applicable if there is no communication between the battery storage system and the notebook.
 Connect the USB cable directly from the battery storage system.




Figure 5-5: USB port of BMZ ESS battery, inner side of housing

Loosen the cable binder of the USB cable carefully using a side cutter and pull the USB plug internally from the socket (rear wall).

6

Connect the notebook with the battery storage system using the USB cable.
 The notebook must not be connected with the AC grid via the charging cable.

7

Switch on the battery storage system using the push button.



Figure 5-6: push button and LEDs

8

The service software can now be installed and started.

5.2.2 Service software

The software is easy to operate and works with all commonly used Windows versions.

The following functions are possible

- Read battery status (cell voltages, temperatures)
- Firmware update
- Configuration of the battery for parallel mode
- Download log files (for sending to the Service Department via email)
- Prepare PDF report (actual status of the battery)

For more information regarding the service software, please refer to the operating manual of the BMZ service tool.

It is a separate document.

Please contact BMZ GmbH for this purpose.

6 Fault/damage event

6.1 Fault indicators

6.1.1 Fault indicators of pilot lamps

Fault indicators of pilot lamps

Two LEDs are provided on the battery storage system.

In case of errors in the battery storage system, they either individually flash in red or flash together in red and green.

Detailed information regarding the flashing pattern is given in the Pilot lamps section (page 79).

Fault indicators of the battery via the inverter

Detailed information regarding error codes displayed by the inverter are given in the corresponding section of the operating manual of the inverter manufacturer.

6.2 Actions to be taken in case of a damage

General information

If the battery storage system is used for the intended purposes, lithium ion batteries do not pose any risk.

If cells and the housing are damaged, there is a risk of contact with electrolytes.

⚠ WARNING



Possible risk to life due to leaking electrolytes.

If you do not observe the following behavioural instructions, they may cause material damage and personal injuries; BMZ GmbH shall not bear any liability in such a case.

- Switch off the battery storage system if it is possible without any risk.
- Ensure adequate ventilation outside.

Prevent these hazardous situations. Otherwise, they may lead to deaths or serious injuries.



Please follow the safety data sheet of the BSW: "Use of stationary lithium solar power accumulators" under www.solarwirtschaft.de

6.2.1 First aid measures

If the battery storage system and the battery modules installed in it are damaged, please initiate the following first aid measures:

Contact with skin and eyes:

- Skin irritations may occur. Wash the skin thoroughly with soap and water.
- Irritations in eyes may occur. Wash eyes thoroughly with water for 15 minutes and then visit a doctor.

Respiratory tracts:

- Generated gases may damage respiratory tracts.
- Ventilate immediately or go in fresh air; in worst cases, call a doctor immediately.

Burns:

- Do not touch the injured person until the de-energised status of the system is ensured
- Take freely lying live cables away from the injured person using non-conductor objects
- Ensuring breathing and the functioning of cardiovascular system is utmost important in case of unconscious patients. If necessary, initiate cardiopulmonary resuscitation immediately
- Let the burn injuries of responding patients cool and cover them with a sterile wound dressing

7 Service and maintenance activities

General information

The manufacturer recommends a regular annual maintenance of the battery system.

Check the following points while doing this:

- Operate the battery with the current firmware
- Battery has not external damage
- Air circulation outside and inside the battery is possible without any problem.
- Air suction is clean and freely accessible
- Histogram of temperature progressions is not problematic and within the permissible temperature range of the battery (see section 5.2)

A deviation from normal operation is shown by the battery indicator of the inverter. The battery has an independent error memory that can be read by an expert authorised by BMZ GmbH.

If you have any queries regarding this, please contact BMZ Service.

BMZ Service Center

If you have queries regarding the BMZ ESS system or require help, you can always contact the BMZ Service Center.

Business hours

Monday to Friday	08:00 AM	to	4:00 PM
Saturday, Sunday and holidays (Bavaria):	Closed		

Contact:

Service telephone	+49 (0) 6188 99 56 9830
Fax	+49 (0) 6188 99 56 699
Website:	www.bmz-central-service.com
Email:	CS.BigPack@bmz-group.com

7.1 Complaint handling

1. Contact a solar technician of BMZ Service via hotline +49 (0)6188 9956-9830 or email CS.BigPack@bmz-group.com.
2. BMZ Service asks solar technicians for the data of the memory (SN, pdf report and log file) -> service tool is required.
3. If it is not available, BMZ Service will send you the latest FW of the service tool and the complaint order free of charge.
4. The solar technician shall fill in the complaint order completely and send it along with the following documents to CS.BigPack@bmz-group.com:
 - Pdf-report of the battery
 - Error.log file
 - Log file of the battery (data from a 10-minute download is sufficient)
 - Installation checklist
 - Proof of purchase / original invoice
5. The solar technician will sign the complaint order to acknowledge that he/she has informed his/her wholesaler about this complaint.
6. If necessary, BMZ Service shall send a packing kit via a forwarding agency
7. If the solar technician packs the solar storage unit in a ready-to-dispatch condition, BMZ Service shall arrange for the pick-up from the solar technician.
8. BMZ Service shall pick up the storage unit from the solar technician, repair it and send it back to the solar technician (if the solar technician cannot rectify the problem).
9. In irreparable cases, BMZ Service shall send a replacement device and pick up the defective storage unit from the solar technician.
10. Business relationships exist only between BMZ and the OEM or its associated authorised dealers (solar technicians, dealers).
11. Direct complaint handling through end customers is ruled out.

If you have questions, please contact:

Tel. +49 (0) 6188 9956-9830 or CS.BigPack@bmz-group.com

8 Warranty conditions

Please contact your authorized dealer for the local warranty conditions.

9 Dismantling and disposal

Introduction

This section describes the dismantling and disposal process for the battery storage system.

9.1 Disposal of the battery storage system

Risk of damage

Only the experts should dismantle the system.

Used batteries are collected by the distributor. Please contact the BMZ Service Center (Tel: +49 (0) 6188 9956 9830, email: CS.BigPack@bmz-group.com) regarding used batteries.

 **CAUTION**



WARNING AGAINST POISONOUS MATERIALS.

Numerous materials have been used in the battery storage system. Some of them may cause damage to people and the battery storage system if not handled properly.

Always follow the local regulations for waste disposal.

Appoint an authorised disposal company for professional disposal.

Prevent these hazardous situations. Otherwise, **they may lead to insignificant or minor injuries.**

Degree of risk of materials

Material group	Degree of risk
Non-ferrous metal	High to very high
Stainless steel	Moderate
Plastics	Moderate
Electronic scrap	High
Batteries	Very high
Cables and lines	High

10 Annexe

Overview

The annexe contains the following documents:

- Declaration of conformity
 - Installation check list
-

10.1 Declaration of conformity

BMZ GMBH
Am Sportplatz 28 · D-63791 Karlstein am Main
Tel: +49 (0)6188 9956-0 · Fax: +49 (0)6188-9956-900
E-Mail: mail@bmz-group.com · Internet: www.bmz-group.com



EC Certification of Conformity

Company: BMZ GmbH
Address: Am Sportplatz 28
63791 Karlstein
Product: Li-ion Battery
Designation: 15S54P US18650V3 55.5V 121.5Ah 6.7kWh
Item no.: 24930-01, 24930-02, 30110-00, 31555-00

We confirm that the designated product corresponds to the substantial requirements of the following European guidelines:

The conformity of the product with the guidelines is proven by the complete compliance to the following mentioned harmonized and not harmonized standards:

2011/65/EC RoHS Directive

Directive of the European Parliament and of the Council on the restriction of the use of certain hazardous substances in electrical and electronic equipment (recast)

EN 62133:2013

Secondary cells and batteries containing alkaline or other non-acid electrolytes - Safety requirements for portable sealed secondary cells, and for batteries made from them, for use in portable applications

2014/30/EU EMC Directive

Directive of the European Parliament and of the Council on the harmonisation of the laws of the member states relating to the electromagnetic compatibility

EN 55014-1:2006 + A1:2009 + A2:2011
EN 55014-2:2015
EN 61000-3-2:2014
EN 61000-3-3:2013

Karlstein am Main, 05.12.2017

Sven Bauer, Managing Director

i.V. Dirk Oestreich, Director R&D

This declaration certifies compliance with the above mentioned directives but does not include a property assurance.

Geschäftsführer
HRB-Nr. 5890 Aschaffenburg
Commerzbank
Sparkasse Aschaffenburg
Deutsche Bank

Sven Bauer
St. Nr.: 122/50444
BIC: COBADEFF795
BIC: BYLADEM1ASA
BIC: DEUTDEFF508

Ust.-ID-Nr.: DE 811770243
IBAN: DE35795400490105770200
IBAN: DE71795500000240004283
IBAN: DE85508700050010501500

BLZ 79540049 Kto. 1057702
BLZ: 79550000 Kto. 240004283
BLZ 50870005 Kto. 010501500

Figure 10-1: EC Declaration of Conformity ESS 7.0 (1)

BMZ GMBH
Am Sportplatz 28 · D-63791 Karlstein am Main
Tel: +49 (0)6188 9956-0 · Fax: +49 (0)6188-9956-900
E-Mail: mail@bmz-group.com · Internet: www.bmz-group.com



EC Certification of Conformity

Company: BMZ GmbH
Address: Am Sportplatz 28
63791 Karlstein
Product: Li-ion Battery
Designation: 15S54P NCM18650-22E 55.5V 121.5Ah 6.7kWh
Item no.: 30890-00, 30891-00, 30892-00, 31560-00

We confirm that the designated product corresponds to the substantial requirements of the following European guidelines:

The conformity of the product with the guidelines is proven by the complete compliance to the following mentioned harmonized and not harmonized standards:

2011/65/EC RoHS Directive

Directive of the European Parliament and of the Council on the restriction of the use of certain hazardous substances in electrical and electronic equipment (recast)

EN 62133:2013

Secondary cells and batteries containing alkaline or other non-acid electrolytes - Safety requirements for portable sealed secondary cells, and for batteries made from them, for use in portable applications

2014/30/EU EMC Directive

Directive of the European Parliament and of the Council on the harmonisation of the laws of the member states relating to the electromagnetic compatibility

EN 55014-1:2006 + A1:2009 + A2:2011
EN 55014-2:2015
EN 61000-3-2:2014
EN 61000-3-3:2013

Karlstein am Main, 05.12.2017

Sven Bauer, Managing Director

i.V. Dirk Oestreich, Director R&D

This declaration certifies compliance with the above mentioned directives but does not include a property assurance.

Geschäftsführer
HRB-Nr. 5890 Aschaffenburg
Commerzbank
Sparkasse Aschaffenburg
Deutsche Bank

Sven Bauer
St. Nr.: 122/50444
BIC: COBADEFF795
BIC: BYLADEM1ASA
BIC: DEUTDEFF508

Ust-ID-Nr.: DE 811770243
IBAN: DE35795400490105770200
IBAN: DE71795500000240004283
IBAN: DE85508700050010501500

BLZ 79540049 Kto. 1057702
BLZ 79550000 Kto. 240004283
BLZ 50870005 Kto. 010501500

Figure 10-2: EC Declaration of Conformity ESS 7.0 (2)

BMZ GMBH
Am Sportplatz 28 · D-63791 Karlstein am Main
Tel: +49 (0)6188 9956-0 · Fax: +49 (0)6188-9956-900
E-Mail: mail@bmz-group.com · Internet: www.bmz-group.com



EC Certification of Conformity

Company: BMZ GmbH
Address: Am Sportplatz 28
63791 Karlstein
Product: Li-ion Battery
Designation: 15S54P US18650NC1 54V 156.6Ah 8.46kWh
Item no.: 32370-00, 33741-00

We confirm that the designated product corresponds to the substantial requirements of the following European guidelines:

The conformity of the product with the guidelines is proven by the complete compliance to the following mentioned harmonized and not harmonized standards:

2011/65/EC RoHS Directive

Directive of the European Parliament and of the Council on the restriction of the use of certain hazardous substances in electrical and electronic equipment (recast)

EN 62133:2013

Secondary cells and batteries containing alkaline or other non-acid electrolytes - Safety requirements for portable sealed secondary cells, and for batteries made from them, for use in portable applications

2014/30/EU EMC Directive

Directive of the European Parliament and of the Council on the harmonisation of the laws of the member states relating to the electromagnetic compatibility

EN 55014-1:2006 + A1:2009 + A2:2011
EN 55014-2:2015
EN 61000-3-2:2014
EN 61000-3-3:2013

Karlstein am Main, 05.12.2017

Sven Bauer, Managing Director

i.V. Dirk Oestreich, Director R&D

This declaration certifies compliance with the above mentioned directives but does not include a property assurance.

Geschäftsführer
HRB-Nr. 5890 Aschaffenburg
Commerzbank
Sparkasse Aschaffenburg
Deutsche Bank

Sven Bauer
St. Nr.: 122/50444
BIC: COBADEFF795
BIC: BYLADEM1ASA
BIC: DEUTDEFF508

Ust.-ID-Nr.: DE 811770243
IBAN: DE35795400490105770200
IBAN: DE71795500000240004283
IBAN: DE85508700050010501500

BLZ 79540049 Kto. 1057702
BLZ: 79550000 Kto. 240004283
BLZ 50870005 Kto. 010501500

Figure 10-3: EC Declaration of Conformity ESS 9.0

BMZ GMBH
Am Sportplatz 28 · D-63791 Karlstein am Main
Tel: +49 (0)6188 9956-0 · Fax: +49 (0)6188-9956-900
E-Mail: mail@bmz-group.com · Internet: www.bmz-group.com



EG-Konformitätserklärung

Firma: BMZ GmbH
Anschrift: Am Sportplatz 28
63791 Karlstein
Produkt: Lithium-Ionen-Batterie
Bezeichnung: 15S54P NCA18650 35E 54V 186,3Ah 10,06kWh
Artikel-Nr. : 37400-00

Für das oben angegebene Produkt bestätigen wir,
dass es den Anforderungen der folgenden
Europäischen Richtlinien und Normen entspricht:

Die Übereinstimmung des Produkts mit den Richtlinien
wird nachgewiesen durch die vollständige Einhaltung der
angeführten harmonisierten und nicht harmonisierten
Normen:

2011/65/EU RoHS-Richtlinie

Richtlinie des Europäischen Parlaments und des Rates
zur Beschränkung der Verwendung bestimmter
gefährlicher Stoffe in Elektro- und Elektronikgeräten

EN 62133:2013

Akkumulatoren und Batterien mit alkalischen oder anderen
nicht säurehaltigen Elektrolyten - Sicherheitsanforderungen
für tragbare gasdichte Akkumulatoren und daraus
hergestellte Batterien für die Verwendung in tragbaren
Geräten

2014/30/EU EMV-Richtlinie

Richtlinie des Europäischen Parlaments und des Rates
zur Angleichung der Rechtsvorschriften der Mitgliedstaaten
über die elektromagnetische Verträglichkeit

DIN EN 55014-1:2016
DIN EN 55014-2:2015
DIN EN 61000-4-2:2009
DIN EN 61000-4-3:2011
DIN EN 62233:2008 + Ber.1:2009

Karlstein am Main, 03.04.2018

Sven Bauer, Geschäftsführer

I.V. Dirk Oestreich, Leiter Entwicklung

Diese Erklärung bescheinigt die Übereinstimmung mit den genannten Richtlinien, sichert jedoch keine Eigenschaften im Sinne des Produkt-
haftungsgesetzes zu.

Geschäftsführer

HRB-Nr. 5890 Aschaffenburg
Commerzbank
Sparkasse Aschaffenburg
Deutsche Bank

Sven Bauer

St. Nr.: 122/50444 Ust.-ID-Nr.: DE 811770243
BIC: COBADEFF795 IBAN: DE35795400490105770200 BLZ: 79540049
BIC: BYLADEM11ASA IBAN: DE7179550000240004283 BLZ: 79550000
BIC: DEUTDEFF508 IBAN: DE85508700050010501500 BLZ: 50870005

Kto. 1057702
Kto. 240004283
Kto. 010501500

Figure 10-4: EC Declaration of Conformity ESS X



Installation Checklist BMZ ESS 7.0



Required accessories	Yes	No
The installer is required to bring the following accessories or spare parts:		
• lifting carriage or hand truck with stair climbing function	☐	☐
• Multimeter (volt meter)	☐	☐
• NH1 fuse (depending on inverter with different nominal values)	☐	☐
SI3.0M-11: 80 A		
SI4.4M-11: 100 A		
SI6.0H-11: 160 A		
SI8.0H-11: 200 A		

Checking installation location	Yes	No
Assembly space is okay		
• Distance to walls > 20cm	☐	☐
• air circulation possible	☐	☐
• no ignition source < 3m	☐	☐
• dry	☐	☐
• even	☐	☐
• clean	☐	☐
• no direct sunlight	☐	☐

Checking for damage	Yes	No
Inspect packaging for transport damage	☐	☐
(Never put a damaged battery into operation!)		
Inspect battery for damage	☐	☐
(Never put a damaged battery into operation!)		

Checking installation	Yes	No
Cabling between inverter and battery is checked		
• 2 pcs 50 mm ² cables connected	☐	☐
• communication cable connected	☐	☐
• no short circuit	☐	☐
• no incorrect polarity of main cables (positive and negative)	☐	☐
• cables not damaged or destroyed	☐	☐

Inserting NH fuses	Yes	No
NH1 fuse is inserted (see operating instruction or installation instruction)	☐	☐

Instructing the end customer	Yes	No
safety instruction for end customer is conducted	☐	☐
operating instruction for end customer is conducted	☐	☐

Reading the battery	Yes	No
Check the battery condition with the service software		
• System time is displayed correctly	☐	☐
• temperature memory is reset	☐	☐
• error memory is reset	☐	☐

SMA parametrization	Yes	No
parametrization of SMA Sunny Island inverter is carried out	☐	☐

Putting system into operation	Yes	No
BMZ battery and SMA Sunny Island inverter are put into service	☐	☐

Figure 10-6: installation check list, part 2