


## DC DISCONNECTOR LOCK



With the DC disconnecter lock, the inverter can be secured against unintentional switching off.

The DC disconnecter lock is only compatible with Tauro inverters.

Padlocks are not included.




42,0410,2647

001-30102020

FRONIUS INTERNATIONAL GMBH

[www.fronius.com](http://www.fronius.com)

## DC DISCONNECTOR LOCK



With the DC disconnecter lock, the inverter can be secured against unintentional switching off.

The DC disconnecter lock is only compatible with Tauro inverters.

Padlocks are not included.



42,0410,2647

001-30102020

FRONIUS INTERNATIONAL GMBH

[www.fronius.com](http://www.fronius.com)